

FIREPRO CENTABUILD

HEAD OFFICE: AUCKLAND (09) 579 0367
CHRISTCHURCH (03) 379 9364

www.firepro.co.nz sales@firepro.co.nz

C/SfB

M766 DATASHEET – Mar 14

Product specifications
can change. Contact
us to ensure you have
our latest datasheet

M766 STUD GRIP WALLBOARD & CEILING ADHESIVE

Provides excellent bonding of plasterboard and wallboards to wooden studs or metal building frames.



- Reduces quantity of nails and screws required and therefore stopping and finishing work, giving a higher quality appearance.
- Superior bridging and gap filling properties reduce the effect of unevenness in frame or board.
- Minimises nail "popping" from timber shrinkage or movement
- Reduces reverberation on metal studs.
- Clean up with water.
- VOC 30 (g/l).

M766 STUDGRIP is a Centabuild **SAFETY-ON-SITE** Product:

- No hydrocarbon based solvents or heavy metals.
- No dangerous clean up solvent required.

SAFETY & HANDLING

Reseal after use.
Store in a cool place.
Do not freeze.
Avoid contact with eyes.
Wash hands after use.

APPLICATION NOTES

1. All surfaces must be dry and free from dust, grease, oil or any other contaminants.
Do not apply in temperatures under 4°C.
2. Apply M766 Studgrip to studs in walnut sized daubs approximately 25mm diameter and 12 mm high.
3. On walls, the daubs should be at maximum 230mm centres and approximately 200mm from the edge of the sheet.
Do not adhere edge of sheet.
4. On ceilings, the daubs of adhesive should be at 200mm centres and 200mm from the recessed edge.
Do not adhere edge of sheet.
5. Fix plasterboard according to manufacturers' specifications within 30 minutes of applying adhesive.
6. Do not permanently nail or screw through adhesive.
7. Nail edges of sheet at 150mm centres. Nail around openings at 300mm centres
8. On ceilings double nail or screw at centre line of sheet in addition to edge fastenings.
9. Temporary blocks should be used on ceilings sheets and alternate studs on long walls to support sheets until adhesive dries.

- Do not remove fasteners too early.
- Not suitable for foil backed boards.
- Do not use on wet, green or greasy timber.
- Permanent nailing or screwing must be used in conditions where adhesive will not dry in 24 hours.
- Do not use in "wet" areas.
- Not tested on fire rated walls.

NOTE: The technical information and suggestions for use and application presented herein represent the best information available to us and are believed to be reliable. If used beyond the situations detailed on this datasheet we advise confirming their suitability before installation. All dimensions are nominal.

We reserve the right to make changes or to withdraw designs and products without notice.